USERGUIDE

C2 COMPACT / C6 COMPACT



English

Deutsch

Français

Español

Italiano

Norsk



www.askproxima.com

TABLE OF CONTENTS INHALTSVERZEICHNIS TABLE DES METÈRES INDICE INDICE INHOLDSFORTEGNELSE

A.	SUPPLIED MATERIAL
B.	SETTING UP PROCEDURE
C.	START - STOP
D.	IMAGE ADJUSTMENTS
E.	REMOTE CONTROL & KEYBOARD
F.	MENU ADJUSTMENTS

M. SERVICE II	IFORMATION2	1
L. FCC STATE	MENT 2	0
TECHNISC	LISTIQUES TECHNIQUES CNICOS ICI	8
SICHERHE INSTRUCT INSTRUCC ISTRUZION	STRUCTIONS	4
AUSTAUSO REMPLACE SUSTITUCI	LACEMENT	3
H. MAINTENA PFLEGE MAINTENA LIMPIEZA MANUTENZ VEDLIKEHO	ZIONE	2
G. OVERVIEW ÜBERSICH PRESENTA VISTA GEN PROSPETT OVERSIKT	TION ERAL	1



LCD Projector with lenscap LCD Projektor mit Schutzkappe Projecteur LCD avec protection lentille Proyector LCD con tapa del lente Proiettore LCD con coperchietto LCD-projektor med linsedeksel




Remote control Fernbedienung Télécommande Control remoto Telecomando Fjernkontroll




Soft Case Soft-Tragetasche Etui souple Funda Valigetta Myk veske




Batteries for remote control Batterien für Fernbedienung Piles pour la télécommande Baterias para el control remoto Pile per il telecommando Batterier til fjernkontroll



Power cord Netzkabel Cordon d'alimentation Cable de alimentación Cavo alimentazione Strømledning



Computer & Mouse Cable Computer- & Mauskabel Câble d'ordinateur et souris Conexión para computador y raton Cavo computer e mouse Data- & muskabel



Video Cable Videokabel Câble vidéo Conexión de vídeo Cavo video Videokabel



USB Mouse Cable USB Mauskabel Cable souris USB Cable raton USB Cavo mouse USB USB Muskabel



Audio Cable Audio Kabel Câble audio Cable de audio Cavo audio Audiokabel



SCART adapter SCART-Anschluß Adaptateur audio Adaptador de Scanner Presa scart SCART-adapter

*) Country dependent

Länder abhängig

Dépendant du pays

Depende del país


Dipendentemente al paese di destinazione

Område avhengig

SETTING UP PROCEDURE ANSCHLUSS INSTALLATION PROCEDIMIENTO DE CONEXIÓN PR


PROCEDIMENTO DI IMPOSTAZIONE OPPSETT

- 1. Connect the projector to:
- the data source with the Computer Cable (1)
- the video source with the Video Cable (2)
- 2. For mouse control use:
- the PS/2 mouse cable (3) attached to (1) or
- the USB mouse cable (4)
- 3. For computer sound connection, use the audio cable (5)
- 4. Connect power cord to projector (6)
- 5. Turn on the projector, then the source(s)








Install batteries Install batteries
Batterien einlegen
Mettre des piles en place
Colocar las baterías
Inserimento pile
Sett inn batteriene




Switch ON to operate remote control










Release projector feet to adjust display angle (1) or manually adjust feet (2)

REMOTE CONTROL & KEYBOARD FERNBEDIENUNG UND BEDIENFELD TELECOMMANDE ET CLAVIER CONTROL REMOTO Y TECLADO TELECOMANDO E TASTIERA FJERNKONTROLL OG TASTATUR






RED light indicates lamp replacement required. Ref. I (LAMP REPLACEMENT) Das ROTE Licht zeigt an, daß die Lampe ausgewechselt werden muß. Ref. I (AUSTAUSCH DER LAMPE)
La lumière ROUGE indique que la lampe doit être remplacée. Ref. I (REMPLACEMENT DE LA LAMPE)
La luz ROJA indica que se debe de reemplazar la bombilla. Ref. I (SUSTITUCIÓN DE LA LÁMPARA) La luce ROSA indica che bisogna sostituire la lampadina. Ref. I (SOSTITUZIONE DELLA LAMPADINA) RØDT lys angir at lampen må byttes ut. Ref. I (SKIFTE LAMPEN)



RED FLASHING when the projector is overheated. Power off and let cool down ROTES BLINKLICHT zeigt Überhitzung des Projektors an. Ausschalten und abkühlen lassen Un CLIGNOTEMENT ROUGE signale la surchauffe du projecteur. Débrancher l'alimentation et laisser refroidir LUZ ROJA PARPADEANTE cuando el proyector está sobrecalentado. Desconectar la alimentación y dejar enfriar La luce ROSSA INTERMITTENTE indica che il proiettore si è surriscaldato. Scollegare l'alimentazione e lasciare raffreddare RØDT BLINKENDE når projektoren er overopphetet. Slå av og la projektoren avkjøle seg.






REMOTE CONTROL & KEYBOARD

FERNBEDIENUNG UND BEDIENFELD FJERNKONTROLL OG TASTATUR

- Activate by pressing actual key(s).
- Zum Aktivieren jeweilige Taste(n) drücken.
- Activer en pressant la (les) touches correspondante(s).
- Activar pulsando la(s) tecla(s) indicativa(s).
- Attivare premendo il / i tasto / i attivi.
- Aktiver ved å trykke på aktuell(e) tast(er).







MENU ADJUSTMENTS MENÜEINSTELLUNGEN OPTIONS DE MENU MENÚ DE AJUSTES IMPOSTAZIONI DAL MENU MENYINNSTILLINGER

Activate/deactivate by: Aktivieren/Deaktivieren mit: Activer et désactiver à l'aide: Activar/desactivar pulsando: Attivare/disattivare premendo: Aktiver/deaktiver med:














Adjusts contrast range from 0 to 100





Adjusts horizontal phase/fine tunes image






Adjusts brightness range from 0 to 100





Adjusts width to image






Adjusts colour intensity






Adjusts position to image size





Synchronizes the projector settings to the active source





Modifies colour temperature balance





Indicates information about active source






Varies the hue in video images

C2 COMPACT / C6 COMPACT


9

www.askproxima.com

MENU ADJUSTMENTS
MENÜEINSTELLUNGEN OPTIONS DE MENU MENÜ DE AJUSTES IMPOSTAZIONI DAL MENU MENYINNSTILLINGER




ANDTEILE PRESENTATION VISTA GENERAL PROSPETTO OVERSIKT



MAINTENANCE PFLEGE MAINTENANCE LIMPIEZA LIMPIEZA MANUTENZIONE VEDLIKEHOLD

- 1. Remove bottom lid to access the filter (fig. 1a & 1b)
- Clean filter (fig. 2)
 Replace clean filter and close bottom lid (fig. 3)
- 4. Clean filter regularly for sufficient air flow






Damp cloth only Nur feucht abwischen Linge humide uniquement Usar sólo un paño húmedo Usare solo un panno umido Kun fuktig klut






Disconnect power Netzstecker ziehen Débrancher l'alimentation Desconectar la alimentación Disinserire la spina Trekk ut strømledningen









Change lamp when lifetime expired. Replace expired lamp only with same type and rating
Wechseln Sie die Lampe nach Ablauf ihrer Lebensdauer aus. Nur lampen des gleichen Typs und gleicher Stärke verwenden
Remplacer la lampe à la fin de sa durée de vie nominale. Ne remplacer la lampe que par un élément de type et puissance identiques
Sustituya la lámpara cuando esté gastada. Sustituya la lámpara gastada sólo por otra del mismo tipo y características
Sostituire la lampadina quando è scarica. Fornita esclusivamente con una lampadina dello stesso tipo e con la stessa potenza
Skift lampe når levetiden er overskredet. Bruk kun lampe av samme type og med samme effekt







Disconnect power Netzstecker ziehen Débrancher l'alimentation Desconectar la alimentación Disinserire la spina Trekk ut strømledningen







Reset lamp timer Zähler auf Null setzen Réinitialiser le compteur de lampe Poner a cero el temporizador de la lámpara Azzerare il timer della lampadina Tilbakestill telleverket for lampen



- 1. Open screws on lamp housing
- 2. Pull out lamp housing
- 3. Insert new lamp housing
- 4. Tighten screws
- 5. Check filter pad (Ref. H)







Refer service to qualified personnel only
Reparaturen sind von Fachpersonal durchzuführen
Confier toute intervention à un professionnel qualifié
La asistencia técnica debe realizares por personal cualificado
Eventuali riparazioni devono essere effettuate esclusivamente da personale qualificato
All service mà overlates til kvalifisert personell





- Read instructions carefully before installation and use
- Vor Verwendung Gebrauchsanweisung sorgfältig lesen
- Lire attentivement les instructions avant de mettre en service et d'utiliser
- Lea atentamente las instrucciones antes de instalar y utilizar
- Leggere attentamente le istruzioni prima dell'installazione e dell'uso
- Les forskriftene omhyggelig før installering og bruk



- Use only original cables
- Nur Originalkabel verwenden
- Utiliser exclusivement des câbles d'origine
- Use únicamente cables y conexiones originales
- Usare esclusivamente cavi originali
- Bruk kun originale kabler



- Expired lamp may explode!
- Abgelaufene Lampen können platzen!
- Une lampe périmée risque de provoquer une explosion!
- Las lámparas gastadas pueden explotar!
 La lampadina scarica può esplodere!
- Lampen kan eksplodere hvis levetiden er overskredet!



- Do not look into projection lens
- Nicht in die Linse sehen
- Ne pas regarder dans l'optique de projection
- No mire directamente hacia el haz luminoso del proyector
- Non guardare nella lente di proiezione
- Ikke se direkte på projektorlinsen



- Do not look into laser beam
- Nicht in den Laserstrahl sehen
- Ne pas regarder le faisceau laser
- No mire directamente hacia el haz luminoso del láser
- Non guardare nel raggio laser
- Ikke se direkte inn i laserstrålen



- Avoid all kinds of moisture
- Vor Nässe schützen
- Protéger contre l'humidité
- Evite todo tipo de humedad
- Evitare di bagnare l'unitàUnngå alle typer fuktighet



- To avoid personal injury, use on stable, hard surface
- Um Verletzungen zu vermeiden, nur auf stabile, harte Oberfläche stellen
- Poser sur un support stable et rigide afin de prévenir tout risque de dommage corporel
- Pare evitar daños personales coloque el equipo sobre una superficie dura y estable
- Per evitare lesioni personali, collocare il proiettore su una superficie stabile e rigida



- To avoid personal injury, use only approved ceiling mount.

- Brukes på stabil, hard overflate for å unngå personskade

- Um Verletzungen zu vermeiden, nur autorisierte Deckenaufhängungen verwenden
- Utiliser exclusivement une fixation plafonnière agréée afin de prévenir tout risque de dommage corporel
- Para evitar daños personales, utilice únicamente el dispositivo de montaje en techo homologado
- Per evitare lesioni personali, utilizzare esclusivamente supporti per il montaggio al soffitto approvati
- Bruk kun godkjent beslag for takmontasje for å unngå personskade



- Ensure free airflow for proper cooling
- Lüftungsschlitze des Gerätes freihalten
- Veiller à ce que le débit d'air soit linéaire afin d'assurer un refroidissement suffisant
- Verifique la libre circulación del aire de ventilación
- Non tappare le griglie di ventilazione per permettere un corretto raffreddamento
- Pass på fri luftgjennomstrømning for tilstrekkelig avkjøling



- Keep away from heat
- Von Hitze fernhalten
- Tenir éloigné de la chaleur
- Manténgalo alejado de fuentes de calor
- Mantenere lontano da fonti di calore
- Unngå sterk varme



- Avoid object and liquid into projector
- Keine Gegenstände und Flüssigkeiten in den Projektor gelangen lassen
- Protéger le projecteur contre toute pénétration d'objets et de liquides
- Evite la entrada de objetos y líquidos dentro del proyector
- Non introdurre né oggetti né liquidi nel proiettore
- Unngå å få gjenstander eller væsker i projektoren




- Connect only with correct grounding and within power specification
- Nur an geerdeten Steckdosen mit angemessener Stromstärke anschließen
- Ne connecter qu'avec une bonne mise à la terre, sur une source électrique conforme à la spécification
- Conectar sólo en enchufes con toma de tierra y la alimentación especificada
- Effettuare i collegamenti esclusivamente con la corretta messa a terra e nel rispetto delle specifiche elettriche
- Tilkobling bare med riktig jording og innenfor spenningsangivelsene



- Protect power cord from damage.
- Netzkabel vor Beschädigung schützen
- Protéger le cordon d'alimentation contre les dommages
- Proteja el cable de alimentación de posibles daños
- Proteggere il cavo di alimentazione elettrica da possibili danni
- Beskytt strømledningen mot skade



- Leave unit to cool down before moving
- Gerät vor dem Abtransport abkühlen lassen
- Laisser le projecteur refroidir avant le transport
- Deje enfriar el equipo antes de moverlo
- Fare raffreddare l'unità prima di trasportarla
- La enheten kjøle seg ned før den flyttes



- Disconnect power when not in use for longer periods
- Netzstecker ziehen, wenn längere Zeit außer Betrieb
- Débrancher le cordon d'alimentation en cas d'inutilisation prolongée
- Desconecte la alimentación cuando no vaya a utilizarlo en un periodo de tiempo largo
- Disinserire la spina quando il proiettore non viene usato per periodi di tempo prolungati
- Trekk ut strømledningen når enheten ikke skal brukes på lengre tid



- Disconnect power when cleaning. Always clean dry or damp, never wet
- Vor dem Reinigen Netzstecker ziehen. Nur trocken oder feucht abwischen, nie naß
- Débrancher le cordon d'alimentation avant de nettoyer. Le linge de nettoyage doit être sec ou humide, en aucun cas détrempé
- Desconecte la alimentación antes de limpiarlo. Use un paño seco o ligeramente humedecido, nunca mojado
- Disinserire la spina durante la pulizia. Pulire sempre con un panno asciutto o umido, ma mai bagnato
- Trekk ut strømledningen ved rengjøring. Bruk alltid tørr eller fuktig klut, aldri våt



- Replace expired lamp only with same type and rating. Qualified personnel only!
- Nur lampen des gleichen Typs und gleicher Stärke verwenden. Nur durch Fachpersonal!
- Ne remplacer la lampe que par un élément de type et puissance identiques. Personnel qualifié uniquement!
- Sustituya la lámpara gastada sólo por otra del mismo tipo y características. Sólo personal cualificado!
- Sostituire la lampadina fornita esclusivamente con una lampadina dello stesso tipo e con la stessa potenza. Solo personale qualificato!
 - Når lampen må skiftes, bruk lampe av samme type og med samme effekt. Må kun utføres av kvalifisert personell!



- Return unit for service if broken or otherwise does not work
- Gerät bei Beschädigung oder sonstigen Störungen an Kundendienst einreichen
- Renvoyer au S.A.V. en cas de dommages physiques ou d'anomalie de fonctionnement
- Envíe el equipo al Servicio de Asistencia Técnica si se estropea
- Rendere l'unità al servizio riparazioni nel caso in cui sia rotta o non funzioni correttamente
- Returner enheten for service hvis den er skadet eller ikke virker som den skal



- Disconnect power if abnormal smell or smoke appears. Return for service
- Bei anomalen Gerüchen oder Rauchbildung Netzstecker ziehen. Kundendienst verständigen
- Si le projecteur dégage une mauvaise odeur ou de la fumée, débrancher le cordon d'alimentation et renvoyer au S.A.V.
- Desconecte la alimentación si aparece humo u olores raros. Envíelo al Servicio de Asistencia Técnica
- Disinserire la spina se si avverte un odore insolito o se fuoriesce fumo dall'unità. Rendere l'inità al servizio riparazioni
- Trekk ut strømledningen hvis du merker unormal lukt eller røyk. Returner enheten for service



- Do not open unit. Risk of electric shock. Refer service to qualified personnel only
- Gerät nicht öffnen. Gefahr des Stromschlags. Reparaturen sind von Fachpersonal durchzuführen
- Risque d'électrocution: ne pas ouvrir le coffret. Confier toute intervention à un professionnel qualifié
- No abra el equipo. Existe riesgo de sufrir una descarga eléctrica. La asistencia técnica debe realizarse por personal cualificado
- Non aprire l'unità. Pericolo di scosse elettriche. Eventuali riparazioni devono essere effettuate esclusivamente da personale qualificato
- Enheten må ikke åpnes. Risiko for elektrisk sjokk. All service må overlates til kvalifisert personell



GENERAL CONDITIONS	ALLGEMEINE DATEN	ENVIRONNEMENT	CONDICIONES GENERALES	CONDIZIONI GENERALI	GENERELLE KRAV	
Storage temperature, sea level	Lagertemperatur, Meeresspiegel	Température de stockage au niveau de la mer	Temperatura de almacenamiento, a nivel del mar	Temperatura di conservazione, a livello del mare	Temperatur ved lagring, havflaten	-20 – 60 °C -4– 140 F
Storage humidity, non-condensing	Lagerfeuchtigkeit, nicht kondensierend	Humidité de stockage, sans condensation	Humedad relativa de almacenamiento sin condensación	Umidità di conservazione, senza condensa	Fuktighet ved lagring, ikke- kondenserende	10-90 % RH
Operating temperature ambient, sea level	Raumtemperatur für Betrieb, Meeresspiegel	Température ambiante de fonctionnement au niveau de la mer	Temperatura ambiente de funcionamiento, a nivel del mar	Temperatura di funzionamento ambiente, a livello del mare	Romtemperatur ved bruk, havflaten	5– 35 °C 41– 95 F
Operating humidity	Betriebsfeuchtigkeit	Humidité de fonctionnement	Humedad relativa de funcionamiento	Umidità di funzionamento	Fuktighet ved bruk	20-80 % RH

PROJECTOR UNIT	PROJEKTOR/ GERÄT	PROJECTEUR	PROYECTOR	UNITÀ DEL PROIETTORE	PROJEKTOR- ENHETEN	
Dimensions (HxWxL)	Maße (HxBxL)	Encombrement (HxPxL)	Dimensiones (Alto x Ancho x Largo)	Dimensioni (Alt. x Largh. x Lungh.)	Størrelse (HxBxL)	99x236x282mm (347 incl. lens) 3.9x9.3x11.1 inch (13.7 incl. lens)
Weight	Gewicht	Poids	Peso	Peso	Vekt	3.7kg/8.1lbs.
Projection lens	Linse	Objectif de projection	Lente de proyección	Lente di proiezion	Projeksjonslinse	1.3 zoom ratio f=38-50mm F=1.8-2.1
Projection distance	Projektionsabstand	Distance de projection	Distancia de proyección	Distanza di proiezione	Projeksjons-avstand	1.1-10m 3.6-32.5 ft
Keystone correction	Trapezentzerrung	Compensation de distorsion trapézoïdale	Corrección de la clave	Correzione della deformazione	Keystone-korreksjon	10 degrees
Projection lamp	Projektionslampe	Lampe de projection	Lámpara para proyección	Lampadina di proiezione	Projeksjonslampe	120 W UHP
Light output	Lichtleistung	Puissance dé clairement	Potencia luminosa	Erogazione luminosa	Lysstrøm	SVGA: 800 ANSI lumen XGA: 900 ANSI lumen
Light valve	Lichtverstärker- Röhre	Valeur lumineuse	Diafragma	Rele ottico	Lysrør	3x0.9 inch polysilicon TFT LCD
Colors	Farben	Couleurs	Colores	Colori	Farger	16.7 MILLION
Contrast	Kontrast	Contraste	Contraste	Contrasto	Kontrast	300:1
Pixels	Auflösung	Résolution	Pixels	Pixel	Piksler	SVGA: 800x600x3 XGA: 1024x768x3

⚠ Subject to change

Änderungen vorbehalten

Sous réserve de modifications

Sujetos a posibles cambios


Soggetti a modifica

PROJECTOR UNIT	PROJEKTOR/ GERÄT	PROJECTEUR	PROYECTOR	UNITÀ DEL PROIETTORE	PROJEKTOR- ENHETEN	
Video frequency	Videofrequenz	Entrée ordinateur	Frecuencia de vídeo	Frequenza video	Videofrekvens	12-150MHz
Horizontal sync.	Horizontalfrequenz	Sync. horizontale	Sinc. horizontal	Sinc. orizz.	Horisontal synk.	15-100KHz
Vertical sync.	Vertikalfrequenz	Sync. verticale	Sinc. vertical	Sink. vert.	Vertikal synk.	43.5-130 Hz
Computer input	Computereingang	Entrée ordinateur	Entrada de señal del ordenator	Ingresso computer	Datamaskin-inngang	0-1Vpp
Audio input	Audioeingang	Entrée audio	Entrada de audio	Ingresso audio	Lydinngang	1VRMS
Speakers	Lautsprecher	Haut-parleurs	Altavoces	Altoparlanti	Høyttalere	2x1 W
Conformance	Prüfzeichen	Conformité	Homologación	Conformità	Oppfyller kravene til	CE, UL, CUL GOST R, FCC Subpart J, Part 15
Power supply	Netzteil	Alimentation électrique	Suministro de corriente	Alimentazione elettrica	Strømforsyning	100-240 VAC, 50-60Hz 2,5-1 A
Computer compatibility resized to native pixel resolution	Computer- kompatibilität. Resizing auf Originalauflösung (Pixel)	Compatibilité ordinateur au redimensionnement de la résolution d'origine (pixels)	Compatibilidad del ordenador ajustada a la resolución pixels. Resolución en pixels	Compatibilità computer (riclassificata in base alla risoluzione pixel originaria)	Datamaskin- kompatibilitet, størrelse endret til naturlig pikseloppløsning	640x480 720x400 800x600 832x624 1024x768 1152x864 1152x870 1280x1024
Video compatibility	Videokompatibilität	Compatibilité vidéo	Compatibilidad de vídeo	Compatibilità video	Video- kompatibilitet	PAL, BGHI, N, combination N, M. NTSC M, N, 4.43, Japan. SECAM

Subject to change Änderungen vorbehalten Sous réserve de modifications Sujetos a posibles cambios Soggetti a modifica


PROJECTION DISTANCES	PROJEKTIONS- ABSTÄNDE	DISTANCES DE PROJECTION	DISTANCIAS DE PROYECCIÓN	DISTANZE DI PROIEZIONE	PROJEKSJONS- AVSTANDER	
WIDE	WEITWINKEL	GRAND ANGULAIRE	GRAN ANGULAR	GRANDANGOLO	VIDVINKEL	
Distance	Entfernung	Distancia	Distance	Distanza	Avstand	1.1-10m/3.6-32.5 ft
Diagonal	Diagonale	Diagonal	Diagonale	Diagonale	Diagonal	0.7-6.5m/2.3-21.1 ft
Width	Breite	Largeur	Ancho	Larghezza	Bredde	0.6-5.2m/1.9-16.9 ft
Height	Höhe	Hauteur	Alto	Altezza	Høyde	0.5-3.9m/1.6-12.7 ft
TELE	TELEOBJEKTIV	TELEOBJECTIF	TELEOBJETIVO	TELEOBIETTIVO	TELE	
Distance	Entfernung	Distancia	Distancia	Distanza	Avstand	1.1-10m/3.6-32.5 ft
Diagonal	Diagonale	Diagonal	Diagonal	Diagonale	Diagonal	0.6-5.2m/1.9-16.9 ft
Width	Breite	Largeur	Ancho	Larghezza	Bredde	0.5-4.2m/1.6-13.7 ft
Height	Höhe	Hauteur	Alto	Altezza	Høyde	0.35-3.2m/1.1-10.4 ft

Variation of +/- 10%. Abweichung von +/- 10% Variation de +/- 10% Variazione di +/- 10% Variación de +/- 10% Variasjon på +/- 10%



TECHNICAL DATA

TECHNISCHE DATEN CARACTERISTIQUES TECHNIQUES DATOS ÉCNICOS DATI TECNICI TEKNISKE DATA



FCC STATEMENT

ing device, pursuant to Subpart J of Part 15 of FCC rules. Only peripherals (computer input/output devices, terminals, printers, etc.) certified to comply with the Class A limits may be attached to a computer that complies with Class A limits. When connecting to a peripheral device, a shielded input/output cable is required to ensure compliance with FCC rules. The shielded cable that must be used is supplied with the equipment. Operation with non-certified peripherals or non-shielded cables is likely to result in interference to radio and TV reception.

, if not installed and used in accordance with the instruction manual, may cause interference to radio and television reception. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of the FCC rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the projector with respect to the receiver.
- Plug the equipment to a different outlet so that equipment and receiver are on different branch circuits.
- Fasten cables using mounting screws to ensure adequate EMI control.

nications Commission (FCC): "How to identify and resolve radio and TV interference problems", available from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

M

SERVICE INFORMATION



This product contains no user serviceable parts.

Attempts to modify mechanics or electonics inside the housing will violate any warranties, and may be hazardous.

If for any reason the product fails to work properly, please contact your dealer for technical support. Prapare a list of the sympoms you observe to diagnosing easier for your dealer.

Please also include the following:

- Serial number of the unit
- Date code
- Software revision (under Main Menu selection ADVANCED/SERMCE/INFO)
- Connected source information (under main menu selection HELP).

For local ASK representation please refer to our web page at

www.askproxima.com